



GHS Ver 6 / Compiler 2012 License Requirement Guidance

Update : 2012.April




Copyright © 2012 Advanced Data Controls Corp. & Green Hills Software, Inc. All right reserved.

License Requirement


Step 1

1. Please do not forget to insert the **USB Dongle** on your PC.
(In case of Floating License, USB Dongle is not required)
2. Please start **licinfoe.bat** by the DOS window as follows.
3. Please enter any key.



Step 2

1. **lic-request.txt** will be generated automatically in the installed folder of GHS product after you run **licinfoe.bat** by DOS window.
2. Please click **lic-request.txt**.



Step 3


1. Here is the license request format generated by lic-request.txt.
2. If PC detects the USB Dongle, the server code will be starting from 32# as follows. Please check if your server code starts from 32# or not .
In case of Floating license, please disregard 32# server code issue.

```
C:\GHS\PPC.V6\multi_61\lic-request.txt
ファイル(F) 編集(E) 表示(V) 検索(S) ウィンドウ(W) 49: 1
- PACKAGE INFORMATION
# Product Distribution List
# CD_RN: RN110909
# Created: Mon Mar 12 19:35:20 2012
# Host: win32
# Title: ide-ppc.910
# Serial: xxxxx
ide-ppc-090100.lst
licinfoe.bat: Rev.120301
- MACHINE INFORMATION
=====↓
Host OS: Windows
Server code for PC-XXXXX: 32#0x208fdd97
(Etan code: 65536/0334 5012 83)
DongleKey: ID(K):0x00000000
=====↓
日本語(Shift-JIS) 挿入モード
```

License Installation


Step 1

1. Start **mladmin.exe** in the GHS package installation folder.




Step 2

1. Please select the **License my MULTI products** in the mldadmin.exe.




Step 3

1. Please select the **install a computer or dongle-locked license file** in the mldadmin.exe



Step 4

1. Please select the license file (xxxxx.ghslic)



Step 5

1. You will see the message "The licenses have been installed successfully"
The license installation work is completed.

